Dewatering well with AMPHIBIA

Field Type of work **Boundary conditions** Construction **Excavation type** Type of material(s) Sequence of installation

Level of risk Type of protection Underground waterproofing Reinforced concrete Aquifer New

HYDRO-REACTIVE SYSTEM

Before pouring concrete

Confined

Waterproofing barrier



- 1. Soil
- 3. Non-woven textile + net
- 5. Lean concrete
- 7. AKTI-VO 201
- 9. Protective screed (optional)
- 11. Granular bentonite
- 13. Stainless steel cap sealed with AKTI-VO 201
- 15. Poured concrete to fill the raft

- 2. Drainage area
- 4. Flanged pipe with cramp-irons (stainless or galvanised)
- 6. AMPHIBIA 3000 GRIP
- 8. WT 102
- 10. RC raft foundation (shaped) suitable to withstand hydraulic pressures and exempt from defects
- 12. Poured concrete to fill the well
- 14. Welded bolts

