AMPHIBIA 3000 GRIP pre-applied installation - sealing of penetrations

Field Type of work **Boundary conditions** Construction **Excavation type** Type of material(s) Sequence of installation Level of risk

Underground waterproofing Reinforced concrete

Aquifer New Free

BENTONITIC SYSTEM

Before pouring concrete

High


Waterproofing barrier



- 1. Penetration (pre-applied installation)
- 3. AMPHIBIA 3000 GRIP

Type of protection

- 5. AKTI-VO 201 after casting concrete
- 7. BI MASTIC and/or AMPHIBIA SAFETY TAPE
- 9. Rigid insulation panels or non-woven textile (min 250 g/m²)
- 2. AKTI-VO 201 already crystallized before pouring concrete
- 4. RC structure suitable to withstand hydraulic pressures and exempt from defects
- 6. AMPHIBIA 3000 GRIP patch all around the penetration
- 8. Hose clamp
- 10. Well compacted soil without voids



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chânce of seepage.
The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.
(*) Attendere qualche ora tra la sua posa ed il successivo getto al fine di consentire la reticolazione del mastice idroespansivo all'aria e quindi la sua adesione alle superfici da sigillare.

