AMPHIBIA with diaphragm wall

Field Type of work **Boundary conditions Building construction Excavation type** Type of material(s) Sequence of installation Level of risk

Underground waterproofing Reinforced concrete

Aquifer New Free

HYDRO-REACTIVE SYSTEM

Before pouring concrete

Waterproofing barrier



1. Soil

3. Lean concrete blinding

5. AMPHIBIA 3000 GRIP


Type of protection

7. Connectors sealed with AKTI-VO 201

9. WT 102

11. RC foundation wall suitable to withstand hydraulic pressures and exempt from defects

- 2. Diaphragm walls
- 4. Smoothing or non-degradable rigid panel
- 6. AMPHIBIA SAFETY TAPE or BI MASTIC
- 8. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 10. BI MASTIC



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.
The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.

(**) Install SAFETY TAPE BT between the two edges of AMPHIBIA 3000 GRIP (alternatively on wooden boards it is possible to fix the overlaps by stapling): see (1)

