**Excavation type** Type of material(s) Sequence of installation

Level of risk Type of protection Roofing protection

Reinforced concrete / Prefabricated structures

Percolation water New / Existing

AQUASCUD SYSTEM


High

Waterproofing barrier / Drainage



- 1. RC vertical structure
- 3. Suitable sloped concrete screed
- 5. AQUASCUD SYSTEM
- 7. Ceramic floor tiles laid with C2-type adhesive (preferably with an S1 and S2 deformation class)
- 9. Skirting board

- 2. Horizontal structure
- 4. AQUASCUD JOIN or AQUASCUD JOIN BT
- 6. Deformable separating element suitable to absorb thermal expansions
- 8. Low elastic modulus sealant solvent-free



PLEASE NOTE: Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO. The waterproofing SYSTEMs must be installed continuously all along the whole structure subjected to intervention, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint (e.g. dilatation joints on the screeds, structural joints etc.), penetration, corner and every possible crack must be sealed with suitable VOLTECO SYSTEMS, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage. The structures must be suitable to withstand every kind of load that they will undergo. Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO All structures have to be suitable to withstand all future loads