## Connection between AMPHIBIA under the raft foundation and AMPHIBIA installed vertically on the internal side of formw

Field Type of work **Boundary conditions Building construction Excavation type** Type of material(s) Sequence of installation Level of risk

Underground waterproofing Reinforced concrete

Aquifer New Free

HYDRO-REACTIVE SYSTEM

Before pouring concrete

High

Waterproofing barrier




- 1. Lean concrete blinding
- 3. AMPHIBIA 3000

Type of protection

- 5. WT 102 conveniently confined (see TDS)
- 7. AMPHIBIA STOPPER with AKTI-VO 201 to seal the distance tubes
- 9. BI MASTIC or AKTI-VO 201
- 11. Suitable element for protection and separation

- 2. AMPHIBIA 3000 GRIP
- 4. Suitable concrete protective screed (optional)
- 6. RC structure suitable to withstand hydraulic pressures and exempt from defects
- 8. AMPHIBIA PRESSURE CORNER 90°
- 10. AMPHIBIA PRESSURE CORNER 270° with SAFETY TAPE BT
- 12. Well compacted soil without voids



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed syntaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.
The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.

1/1