## Construction joint with AMPHIBIA 3000 GRIP under the slab and PLASTIVO on the foundation walls

Field Type of work **Boundary conditions** Construction **Excavation type** Type of material(s) Sequence of installation Level of risk Type of protection

1. Lean concrete

3. Concrete protective screed (optional)

5. WT

7. Fillet with SPIDY 15

9. WT PANEL


11. Element for protection or separation

13. Well compacted soil without voids

Underground waterproofing Reinforced concrete Aquifer New Free HYDRO-REACTIVE SYSTEM Before pouring concrete High Waterproofing barrier

2. AMPHIBIA 3000 GRIP 4. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects 6. RC wall suitable to withstand hydraulic pressures and exempt from defects

- 8. PLASTIVO
- 10. AMPHIBIA PRESSURE LINE
- 12. Rigid insulation panel or non-woven textile (min 250 g/m<sup>2</sup>)



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas. PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage. The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.



