Sequence of installation Level of risk High Type of protection

- 1. Lean concrete
- 3. Concrete protective screed (optional)
- 5. WT
- 7. BI MASTIC or AKTI-VO 201
- 9. AMPHIBIA PRESSURE CORNER 270°
- 11. PVC distance tube to seal
- 13. Rigid insulation panel or non-woven textile (min 250 g/m²)

- Underground waterproofing Reinforced concrete
- Aquifer New Free


HYDRO-REACTIVE SYSTEM

Before pouring concrete

Waterproofing barrier



- 2. AMPHIBIA 3000 GRIP
- 4. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 6. AMPHIBIA 3000 GRIP after casting concrete
- 8. AMPHIBIA PRESSURE CORNER 90°
- 10. RC wall suitable to withstand hydraulic pressures and exempt from defects
- 12. AMPHIBIA STOPPER with AKTI-VO 201 to seal the spacer tube
- 14. Well compacted soil without voids



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, inorizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.

The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.



1/1