Field

Type of work

Boundary conditions

Construction

Excavation type

Type of material(s)

Sequence of installation

Level of risk

Type of protection

Underground waterproofing

Reinforced concrete

Aquifer

New Free

HYDRO-REACTIVE SYSTEM

Before pouring concrete


High

Waterproofing barrier



- 1. Soil
- 3. Lean concrete blinding
- 5. AMPHIBIA 3000 GRIP
- 7. Connectors sealed with AKTI-VO 201
- 9. WT 102
- 11. RC foundation wall suitable to withstand hydraulic pressures and exempt from defects
- 13. GARVO or BI FLEX SYSTEM
- 15. Air shaft

- 2. Diaphragm walls
- 4. Smoothing or non-degradable rigid panel
- 6. AMPHIBIA SAFETY TAPE or BI MASTIC
- 8. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 10. BI MASTIC
- 12. Sloped screed
- 14. PLASTIVO



PLEASE NOTE: Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO. The waterproofing SYSTEMs must be installed continuously all along the whole structure subjected to intervention, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint (e.g. dilatation joints on the screeds, structural joints etc.), penetration, coriner and every possible crack must be sealed with suitable VOLTECO SYSTEMs, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage. The structures must be suitable to withstand every kind of load that they will undergo. Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO All structures have to be suitable to withstand all future loads