Field Type of work

Boundary conditions

Construction **Excavation type**

Type of material(s) Sequence of installation

Level of risk Type of protection Underground waterproofing Reinforced concrete

Aquifer New Confined

HYDRO-REACTIVE SYSTEM

Before pouring concrete


High

Waterproofing barrier



- 1. Lean concrete
- 3. Concrete protective screed (optional)
- 5. WT (optional)
- 7. BI MASTIC
- 9. BI MASTIC or AKTI-VO 201
- 11. RC wall suitable to withstand hydraulic pressures and exempt 12. PVC distance tube to seal
- 13. AMPHIBIA STOPPER with AKTI-VO 201 to seal the spacer
- tube
- 15. Well compacted soil without voids

- 2. AMPHIBIA 3000 GRIP
- 4. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 6. BI FLEX SYSTEM H. 10 0,5 mm
- 8. AMPHIBIA 3000 GRIP after casting concrete
- 10. AMPHIBIA PRESSURE LINE
- 14. Rigid insulation panel or non-woven textile (min 250 g/m²)
- 16. (*) Use BI MASTIC to fix all vertical overlaps of the sheets installed along the formworks



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.

PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.

The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.

