## Construction joint with AMPHIBIA pre-applied on formworks without toe

Field
Type of work
Boundary conditions
Construction
Excavation type
Type of material(s)
Sequence of installation
Level of risk

Type of protection

Underground waterproofing Reinforced concrete Aquifer New Confined HYDRO-REACTIVE SYSTEM Before pouring concrete



1. Soil

3. Formwork

5. Protection screed (optional)

7. WT

9. RC wall suitable to withstand hydraulic pressures and exempt defects

2. Lean concrete

Waterproofing barrier


High

4. AMPHIBIA 3000 GRIP

6. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects

8. Apply staples to fix vertically the sheets on the formworks and BI MASTIC

10. PVC distance tube to seal consequently with AMPHIBIA STOPPER and AKTI-VO 201



PLEASE NOTE: Do not make Amphibia overlaps around the construction joint areas.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, inorizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.

The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.