Construction joint with AMPHIBIA pre-applied on formworks without toe

Field
Type of work
Boundary conditions
Construction
Excavation type
Type of material(s)
Sequence of installation
Level of risk

Type of protection

Underground waterproofing Reinforced concrete

Aquifer New Confined

HYDRO-REACTIVE SYSTEM


Before pouring concrete

High

Waterproofing barrier



- 1. Soil
- 3. Formwork
- 5. Protection screed (optional)
- 7. WT 102
- 9. RC wall suitable to withstand hydraulic pressures and exempt defects
- 2. Lean concrete
- 4. AMPHIBIA 3000 GRIP
- 6. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 8. Apply staples to fix vertically the sheets on the formworks and BI MASTIC
- 10. PVC distance tube to seal consequently with AMPHIBIA STOPPER and AKTI-VO 201



PLEASE NOTE: Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO. The waterproofing SYSTEMs must be installed continuously all along the whole structure subjected to intervention, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint (e.g. dilatation joints on the screeds, structural joints etc.), penetration, coriner and every possible crack must be sealed with suitable VOLTECO SYSTEMs, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage. The structures must be suitable to withstand every kind of load that they will undergo. Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO All structures have to be suitable to withstand all future loads