Field Type of work **Boundary conditions** Construction **Excavation type** Type of material(s)

Sequence of installation

Level of risk Type of protection Underground waterproofing Reinforced concrete

Aquifer New Confined


HYDRO-REACTIVE SYSTEM

Before pouring concrete

Waterproofing barrier



- 1. Soil
- 3. Lean concrete blinding
- 5. AMPHIBIA 3000 GRIP over the pile head
- 7. Steel bars sealed with AKTI-VO 201 or WT 102
- 2. Foundation pile
- 4. Reconstruction with FLOWMIX 70 or FIBRO HFR
- 4. Concrete protective screed (optional)
- 8. RC structure suitable to withstand hydraulic pressures and exempt from defects



PLEASE NOTE: Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO. The waterproofing SYSTEMs must be installed continuously all along the whole structure subjected to intervention, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint (e.g. dilatation joints on the screeds, structural joints etc.), penetration, corner and every possible crack must be sealed with suitable VOLTECO SYSTEMS, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage. The structures must be suitable to withstand every kind of load that they will undergo. Dilatation joints must be realized on the screeds, having position and length according to the Designer's specifics, and sealed with GARVO All structures have to be suitable to withstand all future loads