## Raft foundation - construction joint - wall against piling

Field Type of work **Boundary conditions** Construction **Excavation type** Type of material(s)

Sequence of installation Level of risk Type of protection

Underground waterproofing Reinforced concrete Aquifer

New Free

HYDRO-REACTIVE SYSTEM

Before pouring concrete

High

Waterproofing barrier




1. Piling

3. Lean concrete blinding

5. Connectors sealed with AKTI-VO 201

7. WT

- 2. Soil
- 4. VOLGRIP
- 6. RC raft foundation suitable to withstand hydraulic pressures and exempt from defects
- 8. RC wall suitable to withstand hydraulic pressures and exempt from defects



PLEASE NOTE: The overlap of Volgrip has to be minumum 25 cm far from every construction joint.
PLEASE NOTE: The waterproofing systems must be installed continuously all along the whole structure subjected to intervention and up till the ground level, keeping the continuity between all waterproofed surfaces, horizontal and vertical; any kind of joint, penetration and every possible crack must be sealed with suitable VOLTECO systems, applied in continuity with one another (see VOLTECO technical data sheets), in order to avoid any chance of seepage.

The structures must be suitable to withstand hydraulic pressures and every kind of load that they will undergo.